


07 IBT

Pressure -Torque Conversion Chart

TORC | TECH
Hydraulic Torque Wrenches

Pressure	Torque Value
Bar	Nm
70	112
80	128
90	144
100	160
110	176
120	192
130	208
140	224
150	240
160	256
170	272
180	288
190	304
200	320
210	336
220	352
230	368
240	384
250	400
260	416
270	432
280	448
290	464
300	480
310	496
320	512
330	528
340	544
350	560
360	576
370	592
380	608

Pressure	Torque Value
Bar	Nm
390	624
400	640
410	656
420	672
430	688
440	704
450	720
460	736
470	752
480	768
490	784
500	800
510	816
520	832
530	848
540	864
550	880
560	896
570	912
580	928
590	944
600	960
610	976
620	992
630	1008
640	1024
650	1040
660	1056
670	1072
680	1088
690	1104
700	1120



The data in the pressure torque table are the IBT series factory calibration values. They can be used as a calibration certificate.