



# 1 IBT Pressure -Torque Conversion Chart

**TORC | TECH**  
Hydraulic Torque Wrenches

Pressure	Torque Value
Bar	Nm
70	183
80	209
90	236
100	262
110	288
120	314
130	341
140	367
150	393
160	419
170	446
180	472
190	498
200	524
210	551
220	577
230	603
240	629
250	656
260	682
270	708
280	734
290	761
300	787
310	813
320	839
330	866
340	892
350	918
360	944
370	971
380	997

Pressure	Torque Value
Bar	Nm
390	1023
400	1049
410	1076
420	1102
430	1128
440	1154
450	1181
460	1207
470	1233
480	1259
490	1286
500	1312
510	1338
520	1364
530	1391
540	1417
550	1443
560	1469
570	1496
580	1522
590	1548
600	1574
610	1601
620	1627
630	1653
640	1679
650	1706
660	1732
670	1758
680	1784
690	1811
700	1837



The data in the pressure torque table are the IBT series factory calibration values. They can be used as a calibration certificate.