


2 LOW

Power Head Spare Parts List




Part No	Description	Quantity
SP02LP00	SEAL KIT [3,5,6,7]	1
SP02LP01	BODY ASSEMBLY	1
SP02LP02	SCREW	1
SP02LP04	PISTON ROD ASSEMBLY	1
SP02LP08	END CAP	1
SP02LP09	SCREW	2
SP02LP10	SCREW	8
SP02LP11	ROD END	1
SP02LP12.1	FIXED UPPER PIN	1
SP02LP13	RETAINING RING	2
SP02LP15	SCREW WITH SPRING	1

Part No	Description	Quantity
SP02LP16	SHORT LINK PIN	1
SP02LP17	RING	1
SP02LP18	SWIVEL ASSEMBLY 360°	1
SP02LP18a	SWIVEL ASSEMBLY 180°/360°	1
SP02LP19	1/4" NPT SCREW TYPE OUTER THREAD NIPPLE	1
SP02LP20	1/4" NPT SCREW TYPE OUTER THREAD BODY	1



2 LOW

Cassette Spare Parts List



Part No	Description	Quantity
SP02LC01.2	RIGHT SIDE PLATE [19-22-26-27-30-32-36-41-46-50-55-60]	1
SP02LC02	BRASS BUSHING	2
SP02LC03	LEFT DRIVE PLATE [19-22-26-27-30-32-36-41-46-50-55-60]	1
SP02LC04	REACTION BLOCK EXTENSION [19-22-26-27-30-32-36-41-46-50-55-60]	1
SP02LC05	HEX RATCHET [19-22-26-27-30-32-36-41-46-50-55-60]	1
SP02LC06	RIGHT DRIVE PLATE [19-22-26-27-30-32-36-41-46-50-55-60]	1
SP02LC07.2	LEFT SIDE PLATE [19-22-26-27-30-32-36-41-46-50-55-60]	1

Part No	Description	Quantity
SP02LC08	SCREW M6 x 12	4
SP02LC09	SCREW M5 x 12	4
SP02LC10.2	TOP SPACER	1
SP02LC12	DRIVE PIN	1
SP02LC13	ROLL PIN	2
SP02LC14	DRIVE PIN SPRING	1
SP02LC15.1	SECONDARY DRIVE PAWL [19 - 50 MM]	1
SP02LC15.2	SECONDARY DRIVE PAWL [55 - 60 MM]	1
SP02LC16	SPRING RING	1
SP02LC17	TENSION SPRING	1
SP02LC18.1	PRIMARY DRIVE PAWL [19 - 50 MM]	1

Part No	Description	Quantity
SP02LC18.2	PRIMARY DRIVE PAWL [55 - 60 MM]	1
SP02LC19	SPRING SPACER	1
SP02LC20	TENSION SPRING	1
SP02LC21.1	ROLL PIN	1
SP02LC22	SPACER	2
SP02LC23.2	REACTION PAWL [19-22-26-27-30-32-36-41-46-50-55-60]	1
SP02LC24	SHROUD [19-22-26-27-30-32-36-41-46-50-55-60]	1
SP02LCERA	LONG REACTION ARM	1
SP02LCPAD	SHORT REACTION ARM	1