


4 LOW Power Head Spare Parts List




Part No	Description	Quantity
SP04LP00	SEAL KIT [3,5,6,7]	1
SP04LP01	BODY ASSEMBLY	1
SP04LP02	SCREW	1
SP04LP04	PISTON ROD ASSEMBLY	1
SP04LP08	END CAP	1
SP04LP09	SCREW	2
SP04LP10	SCREW	8
SP04LP11	ROD END	1
SP04LP12.1	FIXED UPPER PIN	1
SP04LP13	RETAINING RING	2
SP04LP15	SCREW WITH SPRING	1

Part No	Description	Quantity
SP04LP16	SHORT LINK PIN	1
SP04LP17	RING	1
SP04LP18	SWIVEL ASSEMBLY 360°	1
SP04LP18a	SWIVEL ASSEMBLY 180°/360°	1
SP04LP19	1/4" NPT SCREW TYPE OUTER THREAD NIPPLE	1
SP04LP20	1/4" NPT SCREW TYPE OUTER THREAD BODY	1



4 LOW

Cassette Spare Parts List



Part No	Description	Quantity
SP04LC01.1	RIGHT SIDE PLATE - [55-60-65-70-75-80]	1
SP04LC02	BRASS BUSHING	2
SP04LC03	LEFT DRIVE PLATE - [55-60-65-70-75-80]	1
SP04LC04	REACTION BLOCK EXTENSION [55-60-65-70-75-80]	1
SP04LC05	HEX RATCHET [55-60-65-70-75-80]	1
SP04LC06	RIGHT DRIVE PLATE [55-60-65-70-75-80]	1
SP04LC07.1	LEFT SIDE PLATE [55-60-65-70-75-80]	1
SP04LC08	SCREW M6x12	4

Part No	Description	Quantity
SP04LC09	SCREW M5x12	4
SP04LC10.1	TOP SPACER	1
SP04LC11	PIN	1
SP04LC12	DRIVE PIN	1
SP04LC13	ROLL PIN	2
SP04LC14	DRIVE PIN SPRING	1
SP04LC15	SECONDARY DRIVE PAWL - [32 - 80 MM]	1
SP04LC15.1	SECONDARY DRIVE PAWL - [36 - 41 MM]	1
SP04LC15.2	SECONDARY DRIVE PAWL - [46 - 55 MM]	1
SP04LC15.3	SECONDARY DRIVE PAWL - [60 - 80 MM]	1
SP04LC16	SPRING RING	1
SP04LC17	TENSION SPRING	1

Part No	Description	Quantity
SP04LC18.1	PRIMARY DRIVE PAWL - [36 - 41 MM]	1
SP04LC18.2	PRIMARY DRIVE PAWL - [46 - 55 MM]	1
SP04LC18.3	PRIMARY DRIVE PAWL - [60-80 MM]	1
SP04LC19	SPRING SPACER	1
SP04LC20	TENSION SPRING	1
SP04LC21.2	ROLL PIN	1
SP04LC22	SPACER	2
SP04LC23.1	REACTION PAWL [55-60-65-70-75-80]	1
SP04LC24	SHROUD [55-60-65-70-75-80]	1
SP04LCERA	LONG REACTION ARM	1
SP04LCPAD	SHORT REACTION ARM	1